



## Installation and removal of pressure gauge cover is possible with one-touch. (PAT.PEND.)

Easy to adjust limit indicator.




## Mounting angle of pressure gauge is selectable depending on the piping direction.

Mounting angle	<b>0</b> °	90°
Illustration of mounting angle	IN OUT	IN OUT
	1000	0700
Mounting angle	180°	<b>270</b> °
Illustration of mounting angle	IN OUT	IN STATE OUT

Pressure gauge anti-revolving mechanism (PAT.PEND.)









## Panel-cut for pressure gauge is not necessary.


In case of panel mounting, the number of holes for taking out the products (pressure gauge plus regulator handle parts) can be reduced into one location. By changing the angle of pressure gauge, the internal volume of a panel can be used effectively.

■Mounting example: In case of aligning three ARG30 in line.









In case of ARG30, dimension in height can be reduced by approx. 30 mm.