

4 indicator window directions offer improved visibility.



Larger push-lock type knob

Easy to lock

Easy to operate with the larger knob and marking every 90° mark



SMC



Easier to insert and remove the tube



Í



Easy identification of product type

Carries		Release b	utton color	
Series	Meter-out	Meter-in	Metric	Inch
	Gray	Light blue	Light gray	Orange
AS-FS AS-FS-U	0	Ø	0	
LUMMA MITHON	Gray	Light blue	White	White
AS-FSG	0	Ø	02	

KE

AS-FG

AS-FP

AS-FM

AS-D

AS-T ASP

ASN

AQ ASV

AK VCHC ASR ASQ



Note) Universal type is not available.

Series Variations

○ Electroless nickel plating type is standardized.

- **○** Stainless steel type is standardized.
- **○**G thread (Face seal) type is standardized.



Speed Controller with Indicator Elbow Type/Universal Type **AS-FS** Series



AS-F

тмн

ASP

ASN

AQ

Flbov



									App	icable	tubing	O.D.						Note 3)	ASD
Model	Port	size	Seal method				Metri	c size						Inch	size			Max. number of	٨C
				2 Note 2)	3.2	4	6	8	10	12	16	1/8"	5/32"	1/4"	5/16"	3/8"	1/2"	rotations	AS
AS1001FS0-M50	M5 :	x 0.8	Contrat and	 Note 4) 	•	٠	•					•	•	٠					AS-FF
AS1001FS0-U10/320	10-32	2UNF	Gasket seal	 Note 4) 	•	٠	•					•	•	٠				°	
AS2001FS0-001		1/8			•	٠	•	•	Note 4)			•	•	٠	•				KE
AS2001FS0-002	_	1/4]		 Note 4) 	٠	•	•	•			Note 4)	•	٠	•	•			
AS3001FS0-002	R NPT	1/4	Note 1) Sealant				٠	•	•	٠				٠	•	•			AS-FG
AS3001FS0-003		3/8					٠	•	•	٠				٠	٠	•			
AS4001FS0-004		1/2]						•	٠	Note 4)					•	•		49-FP
AS2DD1FSD-G01		1/8			•	٠	٠	•	Note 4)										AS-EM
AS2001FS0-G02		1/4]		 Note 4) 	٠	٠	•	•										NO-1 III
AS3DD1FSD-G02	G	1/4	Face seal				•	•	•	٠									AS-D
AS3DD1FSD-G03		3/8]				٠	•	•	٠									
AS4001FS0-G04		1/2]						•	٠	Note 4)] [AS-T

Note 1) "Without sealant" type can be selected as a standard option.

Note 2) Only polyurethane tubing is applicable for ø2

Note 3) There are differences in actual rate as by the indicator window over the maximum number of rotations depending on the individual product. Note 4) Universal type is not available.

Flow Direction Symbols on Body

	Meter-out	Meter-in
Symbol	× ↓	¢

Specifications

Fluid	Air	AS۱
Proof pressure	1.5 MPa	
Max. operating pressure	1 MPa	
Min. operating pressure	0.1 MPa	
Ambient and fluid temperature	-5 to 60°C (No freezing)	VCH
Applicable tubing material	Nylon, Soft nylon, Polyurethane Note), FEP, PFA	ASR
NI-A-XIII		

Note) Use caution at the max. operating pressure when using soft nylon or polyurethane tubing. (Refer to pages 464 and 465 for details.)

▲ Caution

Be sure to read this before handing the products. Refer to back page 50 for Safety Instructions, pages 543 to 546 for Flow Control Equipment Precautions, and pagies 599 to 601 for Specific Product Precautions.

Flow Rate and Sonic Conductance

Mode	əl	AS100	1 FS-M 5□	AS2	⊐⊡1F	S-01	A	52 □□	1FS-	02	AS	300'	IFS	AS4DD1FS		
Tubing	Metric size	ø2	ø3.2 ø4 ø6	ø3.2	ø4	ø6 ø8 ø10	ø3.2	ø4	ø6	ø8 ø10	ø6	ø8	ø10 ø12	ø10	ø12 ø16	
O.D.	Inch size	_	ø1/8" ø1/4" ø5/32"	ø1/8"	ø5/32"	ø1/4" ø5/16"	ø1/8"	ø5/32"	_	ø1/4" ø5/16" ø3/8"	ø1/4"	ø5/16"	ø3/8"	ø3/8"	ø1/2	
C values: Sonic	Free flow	0.2	0.3	0.4	0.6	0.6	0.7	1.0	1.3	1.5	1.6	1.7	2.5	4.4	4.8	
conductance dm³/(s·bar)	Controlled flow	0.2	0.3	0.4	0.7	0.8	0.6	0.9	1	.3	2.1	2.4	3.3	4.4	4.9	
b values: Critical	Free flow	0.3	0.4	0	.2	0.3	0	.3	0	.4	0	.4	0.3	0	.3	
pressure ratio	Controlled flow	0	.2	0	.2	0.3		0	.3			0.3		0	.3	

Note 1) 10-32UNF has the same specification as M5.

Note 2) C and b values are for controlled flow with the needle fully open and free flow with the needle fully closed.





Elbow

Universal



Needle Valve/Flow Rate Characteristics



Note) The numbers above the flow rate characteristic curves in the charts show the applicable tubing outside diameter as defined by the product number.

AK VCHC ASR ASQ

Construction: Elbow Type

Seal method: Gasket seal For M5, 10-32UNF





Seal method: Face seal For G thread



Meter-in type

Component Parts

No.	Description	Material	Note
1	Body A	PBT	
2	Body B	Brass	Electroless nickel plating
3	Knob	POM	
4	Needle	PBT	
5	Needle guide	Brass	Electroless nickel plating
6	U-seal	HNBR	
7	O-ring	NBR	
8	O-ring	NBR	
9	Cassette	—	
10	Seal	NBR	
11	Bonnet A	POM	
12	Bonnet B	POM	
13	Gear	POM	
14	Indicator gear	POM	
15	Clip	Stainless steel	
16	Gasket	NBR/Stainless steel	
17	Seal	NBR	

SMC

Construction: Universal Type

Seal method: Gasket seal For M5, 10-32UNF





Meter-out type

Seal method: Face seal For G thread



Component Parts

No.	Description	Material	Note
1	Body A	PBT	
2	Elbow body	PBT	
3	Body B	Brass	Electroless nickel plating
4	Knob	POM	
5	Needle	PBT	
6	Needle guide	Brass	Electroless nickel plating
7	U-seal	HNBR	
8	O-ring	NBR	
9	O-ring	NBR	
10	O-ring	NBR	
11	Cassette	—	
12	Seal	NBR	
13	Spacer	PBT	ø3.2 and ø1/8" only
14	Bonnet A	POM	
15	Bonnet B	POM	
16	Gear	POM	
17	Indicator gear	POM	
18	Clip	Stainless steel	
19	Gasket	NBR/Stainless steel	
20	Seal	NBR	

Seal method: Sealant For R, NPT thread



Meter-in type

Meter-out type

AS-F TMH ASD AS AS-FE KE AS-FG AS-FP AS-FM AS-D AS-T ASP ASN AQ ASV AK VCHC ASR ASQ

Dimensions: Elbow Type

Seal method: Gasket seal For M5, 10-32UNF





ΠΠ

Metric Size

Metric Size																		[mm]
Model	d	т	н	D1	D3	11	12	13	L4 ʰ	lote 1)	A N	ote 2)	м	W1	W2	Y	v	Weight
Wodel	ŭ	•		51	00		6		Unlocked	Locked	Unlocked	Locked	141	** 1		^	•	[g]
AS12D1FSD-M5E-02	2			E 0		150	20.2						11.0					
AS12□1FS□-U10/32E-02	2			5.0		15.0	20.3						11.9					
AS12D1FSD-M5E-23	2.0			7.0				100										-
AS12□1FS□-U10/32E-23	3.2	M5 x 0.8		1.2	0.4	17.0	01.7	10.9	200	00 F	05	00 F		10.0	15.1		0.0	'
AS12□1FS□-M5E-04	4	10/32UNF	°		9.4	17.2	21.7		39	30.5	35	33.5	100	13.0	15.1	5.5	9.6	
AS12□1FS□-U10/32E-04	4			0.2									13.3					
AS12□1FS□-M5E-06	6	1		10.4		18.6	23.1	16.5	1									8
AS1201FS0-U10/32E-06				10.4		10.0	23.1	10.0										

Note 1) Reference dimensions

Note 2) Reference dimensions of threads after installation

Inch Size																		[mm]
Model	d	т	ц	D1	D2	11	12	12	L4 Ւ	lote 1)	A N	ote 2)	м	W1	wo	v	v	Weight
Woder	u			01	03		62	L3	Unlocked	Locked	Unlocked	Locked	IVI	** 1	VV 2	^	•	[g]
AS12D1FSD-M5E-01	1/0"			7.0														
AS12□1FS□-U10/32E-01	1/0			1.2		17.0	01 7	16.0										-
AS12□1FS□-M5E-03	5/32"	M5 x 0.8	8	82	01	17.2	21.7	10.9	30.0	36.5	35	33.5	13.3	13.6	15.1	5.5	9.6	'
AS1201FS0-U10/32E-03	5/52	10/32UNF	0	0.2	3.4				33.0	00.0	35	55.5	10.0	15.0	13.1	5.5	3.0	
AS12□1FS□-M5E-07	1/4"			11.0		10.6	02.1	16 5]									•
AS12□1FS□-U10/32E-07	1/4			11.2		10.0	23.1	10.5										0

Note 1) Reference dimensions

Note 2) Reference dimensions of threads after installation

而 Ø

.....



Seal method: Gasket seal For M5, 10-32UNF

AS13 IFS1-U10/32-07

AS13D1FS1-M5E-07

11.2

1/4





																			-
Metric Size																		[mm]	AS-
Model	d	т	н	D1	D2	D3	L1	L2	L3	L4	L	5	l la la alua d	A	м	W1	Y	Weight	
AS13[1ES1-M5E-23											Uniocked	LOCKED	Uniocked	LOCKED				lgj	ASE
AS1301FS1-U10-32/23	3.2			7.2			11.6	19.4	175	00.0								-	
AS13D1FS1-M5E-04	4	M5 x 0.8	8	82	96	94		19.8	17.5	33.0	39	36.5	35	33.5	13.3	13.6	96	· /	ASI
AS1301FS1-U10/32-04		10/32UNF	0	0.2	0.0	0.1	11.5	.0.0				00.0		00.0	10.0	10.0	0.0		
AS1301FS1-M5E-06	6			10.4				20.9	20.4	36.6								8	AQ
AS13_1F51-010/32-00																			
																			ASI
Inch Size																		[mm]	A 1/
Model	d	т	н	D1	D2	D3	L1	12	13	14	L	5	1	4	м	W1	Y	Weight	AK
	-		••								Unlocked	Locked	Unlocked	Locked			-	[g]	wan
AS13U1FS1-M5E-01	1/8			7.2															VCH
AS13U1FS1-U10/32-01							172	19.8	17.5	33.8								7	ACD
AS13D1FS1-M5E-03	5/32	M5 x 0.8	8	82	94	9				00.0	39	36.5	35	33.5	13.3	13.6	96		ASK
AS13 1FS1-U10/32-03	0,02	10/32UNF	5	5.2	0.4						00	00.0	00	00.0			0.0		หอน

18.6 20.9 20.4 36.6

AS-F
тмн
ASD
AS
AS-FE
KE
AS-FG
AS-FP
AS-FM
AS-D
AS-T
ASP
ASN
AQ
ASV
AK
VCHC

8

Dimensions: Elbow Type

Seal method: Sealant For R, NPT thread





[mm]

[mm]

Metric Size

Madal	4	Т	ш	D1	D 2	11	1.2	L2 L3 L4 No		Note 1) A Note 2)		м	W/1	wo	v	×	Weight	
woder	a	(R, NPT)	п	וט	03	L.I	L2	L3	Unlocked	Locked	Unlocked	Locked	IVI	VV I	VV Z	^	T	[g]
AS2201FS0-01-23 (S)	3.2			7.2														10 (10)
AS2201FS0-01-04 (S)	4]	10	8.2		19.1	26.2						13.3					13 (13)
AS2201FS0-01-06 (S)	6	1/8	(12.7)	10.4	12			19.1	43.9	42.4	40.8	39.3		20	21.5	6.5	15	14 (13)
AS2201FS0-01-08 (S)	8]	(12.7)	13.2		22.4	29.5						14.2]				15 (14)
AS2201FS0-01-10 (S)	10]		15.9		25.3	32.4						15.6]				16 (15)
AS2201FS0-02-23 (S)	3.2			7.2		20.0	30.2 (30.3)											
AS2201FS0-02-04 (S)	4		17	8.2		20.5	30.2 (30.3)						13.3					23 (24)
AS2201FS0-02-06 (S)	6	1/4	(17.5)	10.4	13	23.4	32.7 (32.8)	22.6	49.7	48.3	44.2	42.8		21.5	24	7.8	16.2	
AS2201FS0-02-08 (S)	8		(17.3)	13.2		23.9	33.2 (33.3)						14.2					24 (25)
AS2201FS0-02-10 (S)	10			15.9		26.9	36.2 (36.3)						15.6					25 (26)
AS3201FS0-02-06 (S)	6			10.4		21.8	32.1	26.4					13.3					47 (49)
AS3201FS0-02-08 (S)	8	1/4	10	13.2	16.6	22.7	33	30.4	63.1	61 7	57.0	56 5	14.2	24 5	28.5	03	10.2	47 (40)
AS3201FS0-02-10 (S)	10	1/4	13	15.9	10.0	26.7	37	35.7	00.1	01.7	57.5	50.5	15.6	24.5	20.5	3.5	13.2	38 (39)
AS3201FS0-02-12 (S)	12			18.5		29.7	40	34.5					17					50 (51)
AS3201FS0-03-06 (S)	6			10.4		21.8	32.1	28.7					13.3	ļ				38 (39)
AS3201FS0-03-08 (S)	8	3/8	10	13.2	16.6	22.7	33	20.7	55 /	54	50.2	18.8	14.2	24 5	28.5	03	10.2	00 (00)
AS3201FS0-03-10 (S)	10	5/0	13	15.9	10.0	26.7	37	28	55.4	54	50.2	40.0	15.6	24.5	20.5	3.5	13.2	29 (40)
AS3201FS0-03-12 (S)	12			18.5		29.7	40	26.8					17					41 (42)
AS4201FS0-04-10 (S)	10		24	15.9		27.4	40.3 (40.2)	36.2					15.6					62 (61)
AS4201FS0-04-12 (S)	12	1/2	24	18.5	18.8	30.8	43.7 (43.6)) 35.1	1 64.1	62.5	5 57	55.4	17	26	29	10	19	64 (63)
AS4201FS0-04-16 (S)	16		(20.0)	23.8		34.8	47.7 (47.6)	32.7					20.6					68 (67)

Т

Note 1) Reference dimensions Note 2) Reference dimensions of threads after installation Note 3) The values in () are for NPT thread.

Inch Size

Madal	4	Т	ш	D1	D 2	14	10	12	L4 N	lote 1)	A N	ote 2)	M	W/1	wo	v	v	Weight
Woder	u	(R, NPT)	п	וט	03		LZ	LS	Unlocked	Locked	Unlocked	Locked		VV I	VV 2	^	T	[g]
AS2201FS0-01-01 (S)	1/8"			7.2		10.1	06.0											10 (10)
AS2201FS0-01-03 (S)	5/32"	1/0	13	8.2	10	19.1	20.2	10.1	40.0	40.4	40.0	20.0	13.3	00	01 5		15	13(13)
AS2201FS0-01-07 (S)	1/4"	1/0	(12.7)	11.2	12	20.8	27.9	19.1	43.9	42.4	40.0	39.3		20	21.5	0.5	15	14 (13)
AS2201FS0-01-09 (S)	5/16"	1		13.2		22.4	29.5						14.2]				15 (14)
AS2201FS0-02-01 (S)	1/8"			7.2		20.0	20.2 (20.2)											22 (24)
AS2201FS0-02-03 (S)	5/32"		47	8.2	1	20.9	30.2 (30.3)						13.3					23 (24)
AS2201FS0-02-07 (S)	1/4"	1/4	(17.5)	11.2	13	23.4	32.7 (32.8)	22.6	49.7	48.3	44.2	42.8		21.5	24	7.8	16.2	24 (24)
AS2201FS0-02-09 (S)	5/16"		(17.5)	13.2	1	23.9	33.2 (33.3)						14.2]				24 (25)
AS2201FS0-02-11 (S)	3/8"	1		15.5	1	26.4	35.7 (35.8)						15.6	1				25 (26)
AS3201FS0-02-07 (S)	1/4"			11.2		21.8	32.1	00.4					13.3					47 (40)
AS3201FS0-02-09 (S)	5/16"	3/8	19	13.2	16.6	22.7	33	30.4	63.1	61.7	57.9	56.5	14.2	24.5	28.5	9.3	19.2	47 (46)
AS3201FS0-02-11 (S)	3/8"			15.5		26.7	37	35.9					15.6					48 (49)
AS3201FS0-03-07 (S)	1/4"			11.2		21.8	32.1	00.7					13.3					20 (20)
AS3201FS0-03-09 (S)	5/16"	3/8	19	13.2	16.6	22.7	33	20.7	55.4	54	50.2	48.8	14.2	24.5	28.5	9.3	19.2	30 (39)
AS32 1FS -03-11 (S)	3/8"	1		15.5	1	26.7	37	28.2	1				15.6	1				39 (40)
AS4201FS0-04-11 (S)	3/8"	1/0	24	15.5	10.0	27.4	40.3 (40.2)	36.2	64.4	CO 5	57	55 A	15.6	00	00	10	10	62 (61)
AS4201FS0-04-13 (S)	1/2"	1/2	(23.8)	19.3	10.0	30.9	43.8 (43.7)	34.7	04.1	02.5	57	55.4	17	20	29	10	19	64 (63)

Note 1) Reference dimensions Note 2) Reference dimensions of threads after installation Note 3) The values in () are for NPT thread.



Dimensions: Universal Type

Seal method: Sealant For R, NPT thread





Metric Size

																	[IIIIII]	AS.
d	т	ц	D1	D 2	D 2	11	12	12	14	L	5		1	м	W1	v	Weight	Л
u			ы	02	03		L2	L3	L4	Unlocked	Locked	Unlocked	Locked	IVI	** 1		[g]	101
3.2			7.2			13.3	24	17.5	36								14	ASI
4	1/0	13	8.2	9.6	10	12.0	25.1	17.5	50	120	12.4	10.0	20.2	13.3	20	15	14	
6	1/0	(12.7)	10.4		12	13.9	26.2	20.4	38.8	43.9	42.4	40.0	39.3		20	15	15	ASI
8			13.2	10.2		16.4	30.1	21.5	40					14.2			16	
4			8.2			16.5	29.9	17.5	40.1					13.3			24	AO
6	1/4	17	11.2	10.0	10	10	33.8	21.4	43.9	40.7	40.0	44.0	40.0	14.2	01 5	10.0	26	na
8	1/4	(17.5)	13.2	12.9	13	19	34.9	23.5	46	49.7	40.3	44.2	42.0	15.6	21.5	10.2	27	101
10			15.9			20.9	38.1	24.7	47.3					17	1		28	AS
6			11.2	10.0		00.0	36	21.4	57.8					13.3			49	
8	4/4	10	13.2	12.9	10.0	20.2	37.1	23.5	59.9	60.1	617	57.0	50 F	14.2	04 5	10.0	50	AK
10	1/4	19	15.9	47.4	10.0	00	41.2	26.1	62.5	03.1	01.7	57.9	50.5	15.6	24.5	19.2	53	
12			18.5	17.4		23	42.5	28.3	64.7					17	1		55	VCH
6			10.4	10.0		00.0	36	21.4	50.1					13.3			41	
8	0/0	10	13.2	12.9	100	20.2	37.1	23.5	52.2		54	50.0	40.0	14.2	045	100	42	ASR
10	3/8	19	15.9		16.6		41.2	26.1	54.8	55.4	54	50.2	48.8	15.6	24.5	19.2	45	ASQ
12			18.5	17.4		23	42.5	28.3	57					17	1		47	
10	4/0	24	15.9	17.4	40.0	25.6	46.4	26.1	61.2		00.5	67	55 A	15.6	00	10	69	
12	1/2	(23.8)	18.5	21	18.8	26.2	48.3	28.3	63.4	64.1	62.5	5/	55.4	17	26	19	72	
	d 3.2 4 6 8 4 6 8 10 6 8 10 12 6 8 10 12 10 12 10 12 10 12	d T 3.2 4 6 1/8 4 6 6 1/4 10 6 6 1/4 10 1/4 10 1/4 10 1/4 11 1/4 12 1/2	$\begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	$ \begin{array}{c c c c c c c c c c c c c c c c c c c $

Inch Size																		[mm]
Model	4	т	ш	D1	D 2	D 2	14	12	12	14	L	.5	/	4	м	W/1	v	Weight
woder	a		п	וט	02	03	L I		LJ	L4	Unlocked	Locked	Unlocked	Locked	IVI	VV I	T	[g]
AS23[]1FS1-01-01 (S)	1/8			7.2	0.6		13.3	24	175	26								14
AS23[]1FS1-01-03 (S)	5/32	1/0	13	8.2	9.0	10	13.9	25.1	17.5	30	120	42.4	10.0	20.2	13.3	20	15	14
AS23[]1FS1-01-07 (S)	1/4	1/0	(12.7)	11.2	10.2	12	16.4	29.1	20.2	38.7	43.9	42.4	40.0	39.3		20	15	15
AS2301FS1-01-09 (S)	5/16			13.2	10.2		10.4	30.1	21.5	40					14.2			16
AS23[]1FS1-02-03 (S)	5/32			8.2			16.5	29.9	17.5	40.1					12.2			24
AS23[]1FS1-02-07 (S)	1/4	1/4	17	11.2	120	13	10	33.8	21.4	43.9	10.7	183	112	128	13.3	21.5	16.2	26
AS2301FS1-02-09 (S)	5/16	1/4	(17.5)	13.2	12.5	15	13	34.9	23.5	46	43.7	40.0	44.2	42.0	14.2	21.5	10.2	27
AS23[]1FS1-02-11 (S)	3/8			15.9			20.9	38.1	24.7	47.3					15.6			28
AS3301FS1-02-07 (S)	1/4			11.2	120		20.2	36	21.4	57.8					13.3			49
AS3301FS1-02-09 (S)	5/16	3/8	19	13.2	12.5	16.6	20.2	37.1	23.5	59.9	63.1	61.7	57.9	56.5	14.2	24.5	19.2	50
AS3301FS1-02-11 (S)	3/8			15.9	17.4		23	41.2	26.1	62.5					15.6			53
AS3301FS1-03-07 (S)	1/4			11.2	120		20.2	36	21.4	50.1					13.3			41
AS3301FS1-03-09 (S)	5/16	3/8	19	13.2	12.5	16.6	20.2	37.1	23.5	52.2	55.4	54	50.2	48.8	14.2	24.5	19.2	42
AS3301FS1-03-11 (S)	3/8			15.9	17.4		23	41.2	26.1	54.8					15.6			45
AS43□1FS1-04-11 (S)	3/8	1/2	24	15.9	17.4	18.8	25.6	46.4	26.1	61.2	64.1	62.5	57	55.4	15.6	26	10	69
AS43[]1FS1-04-13 (S)	1/2	1/2	(23.8)	18.5	21	10.0	26.2	48.3	28.3	63.4	04.1	02.0	57	55.4	17	20	10	72

AS-F

Dimensions: Elbow Type

Seal method: Face seal For G thread





Metric Size

4 L

Ľ

																		[1111]
Madal		-		D1	D 2	14	10	1.0	L4 №	lote 1)	A N	ote 2)	84	14/4	14/0	v	v	Weight
Iviodei	a			וט	03		LZ	L3	Unlocked	Locked	Unlocked	Locked	IVI	VV I	VV2	^	T	[g]
AS2201FS0-G01-23	3.2			7.2														
AS2201FS0-G01-04	4			8.2		19.1	26.2						13.3					14
AS2201FS0-G01-06	6	1/8	13	10.4	12			18.8	43.8	42.4	38.3	36.9		20	21.5	6.5	15	
AS2201FS0-G01-08	8			13.2		22.4	29.5						14.2					15
AS2201FS0-G01-10	10			15.9		25.3	32.4						15.6					16
AS2201FS0-G02-23	3.2			7.2		00.0	00.0											
AS2201FS0-G02-04	4			8.2		20.9	30.2						13.3					26
AS2201FS0-G02-06	6	1/4	17	10.4	13	23.4	32.7	22.6	49.7	48.3	43.2	41.8		21.5	24	7.8	16.2	
AS2201FS0-G02-08	8			13.2		23.9	33.2						14.2					27
AS2201FS0-G02-10	10			15.9		26.9	36.2						15.6					28
AS3201FS0-G02-06	6			10.4		21.8	33	00.4					13.3					
AS3201FS0-G02-08	8	1/4	0.1	13.2	10.0	22.7	33.9	30.4	60.1	61 7	540	50.0	14.2	04.5	00 5	0.0	10.0	55
AS3201FS0-G02-10	10	1/4	21	15.9	10.0	26.7	37.9	35.7	03.1	01.7	54.0	53.2	15.6	24.5	20.5	9.3	19.2	57
AS3201FS0-G02-12	12			18.5		29.7	40.9	34.5	1				17					59
AS3201FS0-G03-06	6			10.4		21.8	33	00.7					13.3					45
AS3201FS0-G03-08	8	0/0	0.1	13.2	10.0	22.7	33.9	20.7	55 4	54	47.0	40 5	14.2	04.5	00.5	0.0	10.0	46
AS3201FS0-G03-10	10	3/0	21	15.9	10.0	26.7	37.9	28	55.4	54	47.9	40.5	15.6	24.5	20.5	9.3	19.2	47
AS3201FS0-G03-12	12			18.5		29.7	40.9	26.8	1				17					49
AS4201FS0-G04-10	10			15.9		27.4	41.8	36.2					15.6					80
AS4201FS0-G04-12	12	1/2	27	18.5	18.8	30.8	45.2	35.1	64.1	62.5	55.1	53.5	17	26	29	10	19	82
AS4201FS0-G04-16	16			23.8		34.8	49.2	32.7]				20.6					86

Т

Note 1) Reference dimensions

Note 2) Reference dimensions of threads after installation

TT. Ø

AS-F

тмн

ASD

AS

AS-FE

KE AS-FG AS-FP

AS-FM

AS-D

Dimensions: Universal Type

Seal method: Face seal For G thread





Metric Size

Metric Size																		[mm]	T.24
Model	d	т	ц	D1	D2	D2	11	12	12	14	L	5	4	1	м	W1	v	Weight	
woder	u	1	п	וט	02	03	LI		LJ	L4	Unlocked	Locked	Unlocked	Locked		VV I	T	[g]	ACD
AS23 1FS1-G01-23	3.2			7.2			13.2	24	17 5	25.7								14	ASL
AS23□1FS1-G01-04	4	1/8	13	8.2	9.6	12	13.0	25.1	17.5	35.7	13.8	121	38.3	36.0	13.3	20	15	15	
AS23 1FS1-G01-06	6	1/0	10	10.4		12	10.0	26.2	20.4	38.5	40.0	42.4	00.0	50.5		20	15	15	ASN
AS23 1FS1-G01-08	8			13.2	10.2		16.4	30.1	21.5	39.7					14.2			16	
AS23 1FS1-G02-04	4			8.2			16.5	29.9	17.5	40.1					12.2			26	AO
AS23 1FS1-G02-06	6	1/4	17	10.4	120	13	10	33.8	21.4	43.9	107	18.3	13.2	11.8	13.3	21.5	16.2	28	
AS23 1FS1-G02-08	8	1/4	17	13.2	12.5	15	13	34.9	23.5	46	43.7	40.5	40.2	41.0	14.2	21.5	10.2	29	V2A
AS23 1FS1-G02-10	10			15.9			20.9	38.1	24.7	47.3					15.6			32	NO V
AS3301FS1-G02-06	6			10.4	120		20.2	36.1	21.4	57.8					13.3			55	A 1/
AS3301FS1-G02-08	8	1/4	21	13.2	12.5	16.6	20.2	38	23.5	59.9	62.1	617	EAG	E2 0	14.2	24 5	10.2	56	AK
AS3301FS1-G02-10	10	1/4	21	15.9	174	10.0	22	42.2	26.1	58	05.1	01.7	54.0	55.2	15.6	24.5	13.2	59	
AS3301FS1-G02-12	12			18.5	17.4		23	43.5	28.3	59.9					17			61	VCHC
AS3301FS1-G03-06	6			10.4	120		20.2	36.6	21.4	50.1					13.3			45	
AS3301FS1-G03-08	8	2/0	21	13.2	12.5	166	20.2	38	23.5	52.2	EE A	54	47.0	16 5	14.2	24 5	10.2	46	ASR
AS3301FS1-G03-10	10	3/0	21	15.9	174	10.0	23	42.2	28.1	50.3	55.4	04	47.9	40.5	15.6	24.5	19.2	47	ASU
AS3301FS1-G03-12	12			18.5	17.4		20	43.5	28.3	52.2					17			49	
AS43□1FS1-G04-10	10	1/0	07	15.9	17.4	100	25.6	47.9	26.1	61.2	64.1	62.5	EE 1	E2 E	15.6	26	10	80	
AS43 1FS1-G04-12	12	1/2	21	18.5	21	10.0	26.2	49.8	28.3	63.4	04.1	02.5	55.1	53.5	17	20	19	82	





Please contact SMC for detailed dimensions, specifications and lead times.

-X12

-X214

1 Lubricant: Vaseline



Example) AS2201FS-01-04S-X12







Example) AS2201FS-01-04S-X21 Note 1) Not particle-free

Note 2) The restrictor is only compatible with the part number of the meter-out type. Note 3) Only the needle and O-ring are fluorine-coated.

10-



-----X214 1

Laser printing

Example) AS2201FS-01-04S-X214

Note) The restrictor is only compatible with the part number of the meter-out type.



4 Clean Series

Example) 10-AS2201FS-01-04S

Note 1) Fluorine grease is used. Note 2) The particle generation class is 5.



AS-FS Series Specific Product Precautions 1

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 543 to 546 for Flow Control Equipment Precautions.

Design and Selection

\land Warning

1. Check the specifications.

The products in this catalog are designed to be used in compressed air systems (including vacuum) only.

If the products are used in an environment where pressure or temperature is out of the specified range, damage and/or malfunction may result. Do not use under such conditions. (Refer to the specifications.)

Please contact SMC when using a fluid other than compressed air (including vacuum).

We do not guarantee against any damage if the product is used outside of the specification range.

2. The products in this catalog are not designed for the use as stop valve with zero air leakage.

A certain amount of leakage is allowed in the product's specifications.

Tightening the needle to reduce leakage to zero may result in equipment damage.

3. Do not disassemble the product or make any modifications, including additional machining.

It may cause human injury and/or an accident.

4. The flow rate characteristics for each product are representative values.

The flow rate characteristics are characteristics of each individual product. Actual values may differ depending on the piping, circuitry, pressure conditions, etc.

- Sonic conductance (C) and critical pressure ratio (b) values for products are representative values. The speed controller's controlled flow values are with the needle fully open and free flow with the needle fully closed.
- 6. Check if PTFE can be used in application.

PTFE powder (Polytetrafluoroethylene resin) is included in the seal material for piping taper thread of male thread type. Confirm that the use of it will not cause any adverse effect on the system.

Please contact SMC if the Material Safety Data Sheet (MSDS) is required.

Mounting

\land Warning

1. Operation Manual

Install the products and operate them only after reading the Operation Manual carefully and understanding its contents. Also, keep the Operation Manual where it can be referred to as necessary.

- Ensure sufficient space for maintenance activities. When installing the products, allow access for maintenance.
- **3. Tighten threads with the proper tightening torque.** When installing the products, follow the listed proper torque.

Mounting

\land Warning

4. After pushing the knob down to lock, confirm that it is locked.

It should not be possible to rotate the knob to the right or to the left. If the knob is pulled with force, it may break. Do not pull the knob with excessive force.



Locked Unlocked

5. Check the degree of rotation of the needle valve.

The products in this catalog are retainer type so that the needle is not removed completely. Over rotation will cause damage.

- 6. Do not use tools such as pliers to rotate the knob. It can cause idle rotation of the knob or damage.
- 7. Verify the air flow direction.

Mounting backward is dangerous, because the speed adjustment needle will not work and the actuator may lurch suddenly.

8. Adjust the speed by opening the needle slowly from the fully closed state.

Loose needle valves may cause unexpected sudden actuator lurching.

When a needle valve is turned clockwise, it is closed and actuator speed decreases. When a needle valve is turned counterclockwise, it is open and actuator speed increases.

9. Do not apply excessive force or shock to the body or fittings with an impact tool.

It can cause damage or air leakage.

- 10. For handling One-touch fittings, refer to the Fittings and Tubing Precautions on pages 13 to 17.
- 11. To install/remove the product, use an appropriate wrench to tighten/loosen at the supplied nut on body B.

Do not apply torque at other points as the product may be damaged. Rotate body A manually for positioning after installation.

12. Do not use body A and/or elbow body for applications involving continuous rotation.

Body A and the fitting section may be damaged.

Universal



AS-F
ТМН
ASD
AS
AS-FE
KE
AS-FG
AS-FP
AS-FM
AS-D
AS-T
ASP
ASN
AQ
ASV
AK
VCHC
ASR ASQ



AS-FS Series Specific Product Precautions 2

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 543 to 546 for Flow Control Equipment Precautions.

Mounting

Caution For M5, 10-32UNF

Tightening method

First, tighten it by hand, then give it an additional 1/6 turn to 1/4 turn with a wrench. A reference value for the tightening torque is 1 to 1.5 N·m.

Note) Excessive tightening may damage the thread portion or deform the gasket and cause air leakage.

If the screw is too shallowly screwed in, it may come loose or air may leak.

Chamfered area for female thread

 Conforming to ISO 16030 (air pressure fluid dynamics – connection – ports and stud ends), the chamfered dimensions shown in the table below are recommended.



Female thread	Chamfered dimension ø D
size	(Recommended value)
M5	5.1 to 5.4
10-32UNF	5.0 to 5.3

For R, NPT Thread (With sealant)

Tightening method

 The proper tightening torques of the fittings are as shown in the table below. As a guide, tighten it by hand, then turn it two or three turns with a wrench. Check the dimensions of each product for the hexagon width across flats.

Connection thread size	Proper tightening torque [N·m]
NPT, R1/8	3 to 5
NPT, R1/4	8 to 12
NPT, R3/8	15 to 20
NPT, R1/2	20 to 25

Chamfered area for female thread

By chamfering as shown in the table below, machining of threads is easier and effective for burr prevention.



Connection	Chamfered dimension øD (Recommended									
thread size	Rc	NPT, NPTF								
1/8	10.2 to 10.4	10.5 to 10.7								
1/4	13.6 to 13.8	14.1 to 14.3								
3/8	17.1 to 17.3	17.4 to 17.6								
1/2 21.4 to 21.6 21.7 to 21.9										
* For Uni	For Uni thread, Rz 12.5 is necessary									

For G Thread (Face seal type)

Tightening method

First, tighten the threaded portion by hand, then use a proper wrench, which could be suitable for the width across flats of the hexagon body, to tighten it further at a wrench tightening angle shown in the table below. For a tightening torque guide, refer to the table below. Check the dimensions of each product for the hexagon width across flats.

Connection thread size	Wrench tightening angle after hand-tightening [deg]	Proper tightening torque [N·m]
G1/8	10 to 20	3 to 4
G1/4	15 to 35	4 to 5
G3/8	15 to 35	8 to 9
G1/2	15 to 35	14 to 15

Caution For G Thread (Face seal type)

Chamfered area for female thread (Recommended value)

 Conforming to ISO 16030-2001, the chamfered dimensions shown in the table below are recommended. By chamfering as shown in the table below, machining of threads is easier and effective for burr prevention.



Nominal thread	Chamfered dimension øD							
size	Min.	Max.						
1/8	9.8	10.2						
1/4	13.3	13.7						
3/8	16.8	17.2						
1/2	21.0	21.4						

2. Use G external threads with G internal threads.

For Uni Thread

Tightening method

 First, tighten the threaded portion by hand, then use a proper wrench, which could be suitable for the width across flats of the hexagon body, to tighten it further at a wrench tightening angle shown in the table below. For a tightening torque guide, refer to the table below.

Connection Female Thread: Rc, NPT, NPTF

Uni thread size	Wrench tightening angle after hand-tightening (deg)	Tightening torque [N·m]
1/8	30 to 60	3 to 5
1/4	30 to 60	8 to 12
3/8	15 to 45	14 to 16
1/2	15 to 30	20 to 22

Connection Female Thread: G

Uni thread size	Wrench tightening angle after hand-tightening [deg]	Tightening torque [N·m]
1/8	30 to 45	3 to 4
1/4	15 to 30	4 to 5
3/8	15 to 30	8 to 9
1/2	15 to 30	14 to 15

2. The gasket can be reused up to 6 to 10 times.

Chamfered area for female thread

By chamfering as shown in the table below, machining of threads is easier and effective for burr prevention.



Connection	Chamfered dimension øD (Recommended value)		
thread size	G	Rc	NPT, NPTF
1/8	10.2 to 10.6	10.2 to 10.4	10.5 to 10.7
1/4	13.6 to 14.0	13.6 to 13.8	14.1 to 14.3
3/8	17.1 to 17.5	17.1 to 17.3	17.4 to 17.6
1/2	21.4 to 21.8	21.4 to 21.6	21.7 to 21.9

* For Uni thread, Rz 12.5 is necessary for sealing at the chamfered part.



AS-FS Series Specific Product Precautions 3

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 543 to 546 for Flow Control Equipment Precautions.

Mounting

▲Caution

1. This product has a stopper for fully close in rotating direction. Excess torque may break the stopper. Table below shows the maximum allowable torque of the knob.

Body size	Maximum allowable torque [N·m]
M5	0.05
1/8	0.07
1/4	0.16
3/8	0.2
1/2	0.4

When performing the piping work, turn the tightening tool in the horizontal direction to the hexagon across flats of the body B so that any moment is not applied to the body A. If the tool is in contact with the body A, this may cause the body B to come off.



2. Actuator speed needs to be checked each time the setting is changed.

Individual product difference due to tolerance of the components, individual actuator difference, operating conditions and temperature, etc. may cause a large variation in the actuator speed, and for this reason, the final actuator speed needs to be checked every time the setting is changed.

3. Force for lifting the knob is specified as shown in the table below.

Larger lifting force than specified in the table below will cause removal of the knob, flow rate not according to the flow rate characteristics curve, incorrect flow indication with the indicator or damage to the product.

Port size	Knob lifting force	
M5 10-32/UNF	1 to 1.5 N	
1/8, 1/4, 3/8, 1/2	3.5 to 4 N	

4. Do not rotate the product by the indicator part. Use a wrench for mounting the product. Otherwise, it may cause damage to the product.

Piping Threads with Sealant

≜Caution

- 1. If the fitting is tightened with excessive torque, a large amount of sealant will seep out. Remove the excess sealant.
- 2. Insufficient tightening may loosen the threads, or cause air leakage.

3. Reuse

- Normally, fittings with a sealant can be reused 2 to 3 times.
 To prevent air leakage through the sealant, remove any loose
- sealant stuck to the fitting by blowing air over the threaded portion.
- 3) If the sealant no longer provides effective sealing, wind sealing tape over the sealant before reusing. Do not use the sealant in any form other than a tape type.
- 4. Once the fitting has been tightened, backing it out to its original position often causes the sealant to become defective. Air leakage will occur.
- 5. Use R external threads with Rc internal threads and NPT external threads with NPT internal threads.

Piping

▲Caution

1. For handling One-touch fittings, refer to the Fittings and Tubing Precautions on pages 13 to 17.

2. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

3. Winding of sealant tape

When screwing together pipes and fittings, etc., be certain that chips from the pipe threads and sealing material do not get inside the pipe. Also, when the sealant tape is used, leave approx. 1 thread ridge exposed at the end of the threads.

