



Process Pump Series PA3000/5000/PAX1000 Series PB1000





Compact, high capacity transfer and recovery of

Long life, 2 to 5 times that of conventional pumps Incorporates a new diaphragm material.

Enlarged bore size and shortened stroke extend life. (compared to series PA2000)

High abrasion resistance and low particle generation No sliding parts in wetted areas.

Self-priming makes priming unnecessary


Process Pump Series PA3000/5000

Automatically operated type/Air operated type (internal switching type) (external switching type)

Automatically operated type

Compatible with a wide variety of fluids

• PA3000: Max. 20/min • PA5000: Max. 45/min




Air operated type 🌡

Control with external switching valve makes constant cycling possible

• Discharge rate is easily controlled. The flow rate can be easily adjusted by the number of external solenoid valve ON/OFF cycles.

EW

- Stable operation is possible even with a minimal flow rate, low pressure operation or the entrainment of gases.
- Can be used when there is repeated stopping of operation.
- Since a switching valve is not contained inside the body, life is longer than the automatically operated type.



diaphragm pump for a wide variety of fluids

Process Pump Variations

Series PA/Double acting pump

Cariaa	Madal	A c	lien	Discharge flow	Material		
Series	Model	AC	tion	rate /min	Body	Diaphragm	
	PA3□□0	Automatically		1 to 20	ADC12	PTFE	
PA3000	PA5□□0	operated type	operated type AIR EX		5 to 45	(aluminum)	NBR
PA5000	PA3□13	Air operated type		0.1 to 12	SCS14 (stainless steel)	DTEE	
	PA5□13	Air operated type		1 to 24		PTFE	
PAX1000	PAX1□12	Automatically operated type with built-in pulsation attenuator	AIR SUP AIR EXH FLUID IN	0.5 to 10	ADC12 (aluminum) SCS14 (stainless steel)	PTFE	
Series PB/Single acting nump							

conteer Brenngre deting pamp									
PB1000	PB1011	Built-in solenoid valve		0.008 to 2	Polypropylene				
	PB1013	Air operated type		0.008 to 0.5	rolypropylene				


Built-in pulsation attenuator

Process Pump Series PAX1000 Automatically operated type

(internal switching type)

Prevents spraying of discharge and foaming in tank

 Built-in pulsation attenuator saves space and makes separate piping unnecessary



Compact single acting

Process Pump Series PB1000 Built-in solenoid valve/


Air operated type (external switching type)

A solenoid valve operated pump that fits in the palm of the hand



PTFF

- 60 x 60 x 41 (mm), 170g
- · Piping and wiring centralized on one side saves space









How to Order

ΡΔ

Body size

3 3/8 standard

5 1/2 standard

ADC12 (aluminum)

1

2

Specifications

1

2

Liquid contact

SCS14 (stainless steel)

body material

Diaphragm material

PTFE

NBR

Process Pump Automatically Operated Type (Internal Switching Type) Series PA3000/5000

3 1 1 0 -

03

03

04

06

Rc

G

NPT T, F, N are order made specifications. Automatically operated type

NPTF

Thread type

Nil

T F

N

Option

Nil

Ν

Connection port size

3/8 (10A): PA3

1/2 (15A): PA5

3/4 (20A): PA5

Body only

* For AIR EXH: AN200-02

With silencer*

ORDER ONLINE


PA3000




PA5000



Symbol





* Each of the values above indicates use at ordinary temperatures with fresh water.






POWER AIRE Process Pump Automatically Operated Type

Series PA3000/5000

Performance Curves/Automatically Operated Type



Selection from flow rate characteristic graphs (PA3000)

Required specification example:


Find the pilot air pressure and pilot air consumption for a discharge rate of 6 Imin and a total lifting range of 25m. [The transfer fluid is fresh water (viscosity 1mPa·S, specific gravity 1.0).]

* If the discharge pressure is required instead of the total lifting height, a total lift of 10m corresponds to discharge pressure of 0.1MPa.

Selection procedures

- 1. First mark the intersection point for a discharge rate of 6 /min and a lifting range of 25m.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for SUP=0.2MPa and SUP=0.5MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.38MPa.

Viscosity characteristics (flow rate correction for viscous fluids)



3. Next find the air consumption rate. Since the marked point is below the curve for 50/min (ANR), the maximum rate will be about 50/min (ANR).

▲Caution

- 1. These flow rate characteristics are for fresh water (viscosity 1mPa·s, specific gravity 1.0).
- 2. The discharge rate differs greatly depending on properties (viscosity, specific gravity) of the fluid being transferred and operating conditions (lifting range, transfer distance), etc.
- 3. Use 0.75kW per 100 / min of air consumption as a guide for the relationship of the air consumption to the compressor.

Selection from viscosity characteristic graph

Required specification example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 2.7 Imin, a total lifting range of 25m, and a viscosity of 100mPa·s.

Selection procedures

- 1. First find the ratio of the discharge rate for fresh water when viscosity is 100mPa·s from the graph below. It is determined to be 45%.
- 2. Next, in the required specification example, the viscosity is 100mPa·s and the discharge rate is 2.7/min. Since this is equivalent to 45% of the discharge rate for fresh water, 2.7/min $\div 0.45 = 6$ /min, indicating that a discharge rate of 6/min is required for fresh water.
- 3. Finally, find the pilot air pressure and pilot air consumption based on selection from the flow rate characteristic graphs.


Viscosities up to 1000mPa·s can be used.





Series PA3000/5000

Operating Principle/Automatically Operated Type



Control unit

- 1. When air is supplied, it passes through the switching valve and enters drive chamber B.
- 2. Diaphragm B moves to the right, and at the same time diaphragm A also moves to the right pushing pilot valve A.
- 3. When pilot valve A is pushed, air acts upon the switching valve, drive chamber A switches to a supply state, and the air which was in drive chamber B is exhausted to the outside.

Drive unit

- 1. When air enters drive chamber B, the fluid in pump chamber B is forced out, and at the same time fluid is sucked into pump chamber A.
- 2. When the diaphragm moves in the opposite direction, the fluid in pump chamber A is forced out, and fluid is sucked into pump chamber B.

4. When air enters drive chamber A, diaphragm B moves to the left pushing pilot valve B.

ORDER

- 5. When pilot valve B is pushed, the air which was acting upon the switching valve is exhausted, and drive chamber B once again switches to a supply state. A continuous reciprocal motion is generated by this repetition.
- 3. Continuous suction and discharge is performed by the reciprocal motion of the diaphragm.






POWER AIRE Process Pump Automatically Operated Type

Series PA3000/5000

Piping and Operation/Automatically Operated Type



▲ Caution

Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid and air leaks, while over tightening can cause damage to threads and parts, etc.

Operation

<Starting and Stopping> Refer to circuit example (1)


- Connect air piping to the air supply port <AIR SUP> and connect piping for the fluid to be transferred to the suction port <FLUID IN> and the discharge port <FLUID OUT>.
- 2. Using a regulator, set the pilot air pressure within the range of 0.2 to 0.7MPa. Then, the pump operates when power is applied to the 3 port solenoid valve of the air supply port <AIR SUP>, the sound of exhaust begins from the air exhaust port <AIR EXH> and fluid flows from the suction port <FLUID IN> to the discharge port <FLUID OUT>. At this time, the ball valve on the discharge side is in an open state. The pump performs suction with its own power even without priming. (Dry state suction lifting range: max. 1m) To restrict exhaust noise, attach a silencer (AN200-02: option) to the air exhaust port <AIR EXH>.
- 3. To stop the pump, exhaust the air pressure being supplied to the pump by the 3 port solenoid valve of the air supply port <AIR SUP>. The pump will also stop if the ball valve on the discharge side is closed.


<Discharge Flow Rate Adjustment>

- Adjustment of the flow rate from the discharge port <FLUID OUT> is performed with the ball valve connected on the discharge side or the throttle connected on the air exhaust side. For adjustment from the air side, use of the silencer with throttle ASN2 (port size 1/4) connected to the air exhaust port <AIR EXH> is effective. Refer to circuit example (1).
- 2. When operating with a discharge flow rate below the specification range, provide a by-pass circuit from the discharge side to the suction side to ensure the minimum flow rate inside the process pump. With a discharge flow rate below the minimum flow rate, the process pump may stop due to unstable operation. Refer to circuit example (2). (Minimum flow rates: PA3000 1/min, PA5000 5/min)

<Reset Button>

 When the pump stops during operation, press the reset button. This makes it possible to restore operation in case the switching valve becomes clogged due to foreign matter in the supply air.





Circuit example (2)






ORDER ONLINE

Series PA3000/5000

Dimensions/Automatically Operated Type









Process Pump Air Operated Type (External Switching Type) Series PA3000/5000

3

03

03

04

06

Rc

G

T, F, N are order made

NPT

NPTF

Thread type

Nil

T* F*

N*

specifications.

Air operated type

Connection port size

3/8 (10A): PA3

1/2 (15A): PA5

3/4 (20A): PA5

PA 3 1 1

Body size

3 3/8 standard

5 1/2 standard

1 ADC12 (aluminum)

SCS14 (stainless steel)

1

Diaphragm material

PTFE

Liquid contact body material

2

Specifications

Model

How to Order


PA3000








Symbol



Air operated type



* Each of the values above indicates use at ordinary temperatures with fresh water.

Note 1) With cycles at 2Hz or more

Note 2) After initial suction of liquid operating at 1 to 7Hz, it can be used with operation at lower cycles. Since a large quantity of liquid will be pumped out, use a suitable throttle in the discharge port if problems occur.

Note 3) With a low number of operating cycles, even a valve with a small Cv factor can be operated.

Recommended Valve

PA3000	VQZ14 ^[] 0 (exhaust center)
PA5000	VQZ24□0 (exhaust center)


Refer to page 21 for further details.






Series PA3000/5000


Performance Curves/Air Operated Type



PA3 Air consumption




PA5 13 Air consumption



100 (%) 400 (%) 100 (%

Viscosity characteristics (flow rate correction for viscous fluids)



Selection from flow rate characteristic graphs (for PA3000)

Required specification example:

Find the pilot air pressure for a discharge rate of 4./min and a total lifting range of 15m. <The transferred fluid is clean water (viscosity 1mPa·s, specific gravity 1.0).>

- Note 1) If the discharge pressure is required instead of the total lifting height, a total lift of 10m corresponds to a discharge pressure of 0.1MPa.
- Note 2) 1 cycle discharge rate PA3000: Approx. 22m/ PA5000: Approx. 100m/ Selection procedure

Selection procedure

- 1. First mark the intersection point for a discharge rate of 4/min and a lifting range of 15m.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for SUP=0.2MPa and SUP=0.3MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.25MPa.
- Note 1) Even when switching cycles are changed for PA3000 with SUP=0.2MPa or PA5000 with SUP=0.2MPa or 0.3MPa, there is almost no change in the lifting height.

Calculating air consumption (for PA3000)

Find the air consumption for operation with a 4Hz switching cycle and pilot air pressure of 0.3MPa from the air consumption graph.

Selection procedure

- 1. Look up from the 4Hz switching cycle to find the intersection with $\ensuremath{\texttt{SUP}=0.3}\ensuremath{\texttt{MPa}}\xspace.$
- 2. From the point just found, draw a line to the Y-axis to find the air consumption. The result is approximately 50*I*/min.

- 1. These flow rate characteristics are for fresh water (viscosity 1mPa·s, specific gravity 1.0).
- The discharge rate differs greatly depending on properties (viscosity, specific gravity) of the fluid being transferred and operating conditions (lifting range, transfer distance), etc.

Selection from viscosity characteristic graph

Required specification example:

Find the pilot air pressure for a discharge rate of 2.7 I min, a total lifting range of 25m, and a viscosity of 100mPa s.

Selection procedure

- 1. First find the ratio of the discharge rate for fresh water when viscosity is 100mPa·s from the graph at the left. It is determined to be 45%.
- 2. Next, in the required specification example the viscosity is 100mPa·s and the discharge rate is 2.7/min. Since this is equivalent to 45% of the discharge rate for fresh water, 2.7/min ÷ 0.45 = 6/min, indicating that a discharge rate of 6/min is required for fresh water.
- 3. Finally, find the pilot air pressure and pilot air consumption rate based on selection from the flow rate characteristic graphs.

Viscosities up to 1000mPa·s can be used.






POWER OAIRE Process Pump Air Operated Type

Type Series PA3000/5000

Operating Principle/Air Operated Type




- 1. When air is supplied to P1 port, it enters drive chamber A.
- 2. Diaphragm A moves to the left, and at the same time diaphragm B also moves to the left.
- 3. The fluid in pump chamber A is forced out to the discharge port, and the fluid is sucked into pump chamber B from the suction port.
- 4. If air is supplied to the P2 port, the opposite will occur. Continuous suction and discharge of fluid is performed by repeating this process with the control of an external solenoid valve (5 port valve).





Series PA3000/5000

Piping and Operation/Air Operated Type



≜Caution

Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid and air leaks, while over tightening can cause damage to threads and parts, etc.

Operation


<Starting and Stopping> Refer to circuit example

- Connect air piping Note 1) to the pilot air supply ports <P1>, <P2> and connect piping for the fluid to be transferred to the suction port <FLUID IN> and the discharge port <FLUID OUT>.
- 2. Using a regulator, set the pilot air pressure within the range of 0.1 to 0.5MPa. Then, the pump operates when power is applied to the solenoid valve Note 2) of the pilot air supply port and fluid flows from the suction port <FLUID IN> to the discharge port <FLUID OUT>. At this time, the ball valve on the discharge side is in an open state. The pump performs suction with its own power even without priming. (Note 3) Dry state suction lifting range: PA3 1m, PA5 up to 0.5m) To restrict exhaust noise, attach a silencer to the solenoid valve air exhaust port.
- 3. To stop the pump, exhaust the air pressure being supplied to the pump with the solenoid valve of the air supply port.

- Note 1) When used for highly permeable fluids, the solenoid valve may malfunction due to the gas contained in the exhaust. Implement measures to keep the exhaust from going to the solenoid valve side.
- Note 2) For the solenoid valve, use an exhaust center 5 port valve, or a combination of residual exhaust 3 port valve and a pump drive 4 port valve. If air in the drive chamber is not released when the pump is stopped, the diaphragm will be subjected to pressure and its life will be shortened.
- Note 3) When the pump is dry, operate the solenoid valve at a switching cycle of 1 to 7Hz. If operated outside of this range, the suction lifting height may not reach the prescribed value.

<Discharge Flow Rate Adjustment>

1. The flow rate from the discharge port <FLUID OUT> can be adjusted easily by changing the switching cycle of the solenoid valve on the air supply port.







Dimensions/Air Operated Type

POWER O AIRE Process Pump Air Operated Type Series PA3000/5000

PA3000 \oplus क 80 85 φ 105 7.5 4-ø7 FLUID OUT 5.5 Rc 3/8 AIR SUP (P1) Rc 1/4 \oplus Æ FLUID OUT € PROCESS PUMP E **n**1 -2 115 $\overline{\bigcirc}$ 6 74.5 ØSWC FLUID P2 44.5 ¢ AIR SUP (P2) 3 32 Rc 1/4 īr=+ 100 130 FLUID IN Rc 3/8 PA5000 4-ø9 179 ۲ \odot 8 6 \oplus \oplus FLUID OUT AIR SUP (P1) Rc 1/2, 3/4 Rc 1/4 112 56 165 56 RESET 6 FLUID OUT PROCESS PUMP 167 132.5 FLUID I N 125.5 103.5 © SMC 58.5 48.5 3 3.5 202 114 AIR SUP (P2) FLUID IN Rc 1/4 Rc 1/2, 3/4








Process Pump Automatically Operated Type with Built-in Pulsation Attenuator (Internal Switching Type) Series PAX1000


How to Order



Symbol



Automatically operated type



specifications.

Specifications

	Model		PAX1112	PAX1212	
Port size Main fluid suction/ discharge port Pilot air supply/ exhaust port			Rc 1/4, 3/8		
			Rc 1/4		
	Fluid conta	ct areas	ADC12	SCS14	
Material	Diaphragm		PTF	E	
	Check valv	e	PTFE, S	SCS14	
Discharge rate Average discharge pressure Pilot air consumption Dry			0.5 to 10 / min		
		sure	0 to 0.6MPa Maximum 150 /min (ANR) Up to 2m (interior of pump dry)		
		Dry			
	Suction lifting range Wet		Up to (liquid insi		
Discharge pu	Isation attenuati	ng capacity	pacity 30% or less of maximum discharge pressure		
Fluid temp	erature		0 to 60°C (with no freezing)		
Ambient te	emperature		0 to 6	50°C	
Pilot air pr	essure		0.2 to 0	.7MPa	
Withstand	pressure		1.05	MPa	
Mounting	position		Horizontal (botto	om facing down)	
Weight			2.0kg	3.5kg	

 \ast Each of the values above indicates use at ordinary temperatures with fresh water.









Process Pump

Automatically Operated Type with Built-in Pulsation Attenuator

Performance Curves/Automatically Operated Type with Built-in Pulsation Attenuator



Viscosity characteristics (flow rate correction for viscous fluids)



Selection from flow rate characteristic graph

Required specification example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 6 Imin and a total lifting range of 25m. [The transfer fluid is fresh water (viscosity 1mPa·S, specific gravity 1.0).]

Series PAX1000

* If the discharge pressure is required instead of the total lifting height, a total lift of 10m corresponds to discharge pressure of 0.1MPa.

Selection procedures

- 1. First mark the intersection point for a discharge rate of 6 /min and a lifting range of 25m.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for SUP=0.2MPa and SUP=0.5MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.45MPa.
- 3. Next find the air consumption. Since the marked point is below the curve for 50 /min (ANR), the maximum rate will be about 50 /min (ANR).

Selection from viscosity characteristic graph

Required specification example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 2.7 Imin, a total lifting range of 25m, and a viscosity of 100mPa·s.

Selection procedure

- 1. First find the ratio of the discharge rate for fresh water when viscosity is 100mPa·s from the graph below. It is determined to be 45%.
- 2. Next, in the required specification example, the viscosity is 100mPa·s and the discharge rate is 2.7/min. Since this is equivalent to 45% of the discharge rate for fresh water, 2.7/min $\div 0.45 = 6/min$, indicating that a discharge rate of 6/min is required for fresh water.
- 3. Finally, find the pilot air pressure and pilot air consumption based on selection from the flow rate characteristic graph.


Viscosities up to 1000mPa·s can be used.





Series PAX1000

Operating Principle/Automatically Operated Type with Built-in Pulsation Attenuator




Control unit

- 1. When air is supplied, it passes through the switching valve and enters drive chamber B.
- 2. Diaphragm B moves to the right, and at the same time diaphragm A also moves to the right pushing pilot valve A.
- 3. When pilot valve A is pushed, air acts upon the switching valve, drive chamber A is switched to a supply state, and the air which was in drive chamber B is exhausted to the outside.
- 4. When air enters drive chamber A, diaphragm B moves to the left pressing pilot valve B.
- 5. When pilot valve B is pushed, the air which was acting upon the switching valve is exhausted, and drive chamber B once again switches to a supply state. A continuous reciprocal motion is generated by this repetition.

Pulsation attenuation chamber

- 1. Pulsation is attenuated by the elastic force of the diaphragm and air in the pulsation attenuation chamber
- 2. When the pressure in the pulsation attenuation chamber rises, the change lever presses the pulsation attenuator intake valve, and air enters the pulsation attenuator air chamber




Pulsation Attenuating Capacity

The process pump generates pulsation because it discharges a liquid using two diaphragms. The pulsation attenuator absorbs 1. When air enters drive chamber B, the fluid in pump chamber B is forced out, and at the same time fluid is sucked into pump chamber A.

ORDER ONLINE

- 2. When the diaphragm moves in the opposite direction, the fluid in pump chamber A is pushed out, and fluid is sucked into pump chamber B.
- 3. The pressure of the fluid that is forced out of the pump chamber is adjusted in the pulsation attenuation chamber and is then exhausted.
- 4. Continuous suction/discharge is performed by the reciprocal motion of the diaphragm.
- 3. Conversely, when pressure drops, the change lever presses the pulsation attenuator exhaust valve, exhausting the air from the air chamber and keeping the diaphragm in a constant position. Note that some time is required for the pulsation attenuator to operate normally.



pressure when discharge pressure increases, and compensates the pressure when discharge pressure decreases. By this means pulsation is controlled.



POWER AIRE






Process Pump

Automatically Operated Type with Built-in Pulsation Attenuator Series PAX1000

Piping/Automatically Operated Type with Built-in Pulsation Attenuator



▲ Caution

Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid leakage, while over tightening can cause damage to threads and parts, etc.

Operation

<Starting and Stopping> Refer to circuit example (1)


- Connect air piping to the air supply port <AIR SUP> and connect piping for the fluid to be transferred to the suction port <FLUID IN> and the discharge port <FLUID OUT>.
- 2. Using a regulator, set the pilot air pressure within the range of 0.2 to 0.7MPa. Then, the pump operates when power is applied to the 3 port solenoid valve of the air supply port <AIR SUP>, the sound of exhaust begins from the air exhaust port <AIR EXH> and fluid flows from the suction port <FLUID IN> to the discharge port <FLUID OUT>. At this time, the ball valve on the discharge side is in an open state. The pump performs suction with its own power even without priming. (Dry state suction lifting range: max. 2m) To restrict exhaust port <AIR EXH>.
- 3. To stop the pump, exhaust the air pressure being supplied to the pump with the 3 port solenoid valve of the air supply port <AIR SUP>. The pump will also stop if the ball valve on the discharge side is closed.

<Discharge Flow Rate Adjustment>

- Adjustment of the flow rate from the discharge port <FLUID OUT> is performed with the ball valve connected on the discharge side or the throttle connected on the air exhaust side. For adjustment from the air side, use of the silencer with throttle ASN2 (port size 1/4) connected to the air exhaust port <AIR EXH> is effective. Refer to circuit example (1).
- 2. When operating with a discharge flow rate below the specification range, provide a by-pass circuit from the discharge side to the suction side to ensure the minimum flow rate inside the process pump. With a discharge flow rate below the minimum flow rate, the process pump may stop due to unstable operation. (Minimum flow rate: PAX1000 0.5*I*/min)

<Reset Button>

1. When the pump stops during operation, press the reset button. This makes it possible to restore operation in case the switching valve becomes clogged due to foreign matter in the supply air.








ORDER ONLINE

Series PAX1000

Dimensions










Process Pump Built-in Solenoid Valve Type/Air operated Type (External Switching Type) Series PB1000


How to Order




Symbol



Built-in solenoid valve type







	Model		PB1011	PB1013	
	Main fluid suction/discharge port		Rc 1/8		
Port size	Pilot air	Supply port	Rc 1	1/8	
	FIIOL all	Exhaust port	M5 x 0.8		
	Fluid cor	tact areas	Polypropylene PP, Stai	nless steel (SUS316)	
Material	Diaphrag	m	PTF	E	
	Check valve Liquid contact seals		PTFE		
			FKM		
Discharge rate			8 to 2000m / min	8 to 500m / min	
Average discharge pressure			0 to 0.6MPa		
Suction lifting range			Up to 2.5m (dry: interior of pump dry)		
Fluid temperature			0 to 50°C (with	no freezing)	
Ambient temperature			0 to 50°C		
Pilot air p	ressure		0.2 to 0.7MPa		
Withstan	d pressure	•	1.05N	ЛРа	
Recomm	ended ope	rating cycle	1 to 10Hz (0.03 to 1Hz also possible depending on conditions Note 2		
Lubrication			Not rec	luired	
Voltage			24VDC	_	
Weight			0.17kg	0.15kg	
Mounting	position		OUT port at top (indic	ation on name plate)	
-		Note 1)	- 0.2		

* Each of the values above indicates use at ordinary temperatures with fresh water.

Note on the transfer of slurry:

Slurry transfer is not possible with Series PB1000 because of deterioration and wear of the check valve seat and the accumulation of particles, which will render the pump inoperable.

Note 1) With low operating cycles, even a valve with a small Cv factor can be operated. Recommended valve/for PB1013 air operated type: SYJ3□4


Note 2) After initial suction of liquid operating at 1 to 7Hz, it can be used with operation at lower cycles. Since a large quantity of liquid will be pumped out, use a suitable throttle in the discharge port if problems occur.




POWER O AIRE

Series PB1000


Performance Curves/Built-in Solenoid Type/Air Operated Type



PB1000 Air consumption



Viscosity characteristics (flow rate correction for viscous fluids)



Selection from flow rate characteristic graphs

Required specification example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 600m /min and a total lifting range of 15m.

- <The transferred fluid is clean water (viscosity 1mPa·s, specific gravity 1.0) solenoid valve cycle 5Hz>
 - * If the discharge pressure is required instead of the total lifting height, a total lift of 10m corresponds to a discharge pressure of 0.1MPa.

Selection procedure

- 1. First mark the intersection point for a discharge rate of 600m/min and a lifting range of 15m.
- 2. Find the pilot air pressure for the marked point. In this case, the point is between the discharge curves (solid lines) for 0.35MPa and 0.5MPa, and based on the proportional relationship to these lines, the pilot air pressure for this point is approximately 0.4MPa.

Calculating air consumption

Find the air consumption for operation with a 5Hz switching cycle and pilot air pressure of 0.35MPa from the air consumption graph.

Selection procedure

- 1. Look up from the 5Hz switching cycle to find the intersection with $\ensuremath{\mathsf{SUP}}\xspace=\!0.35\ensuremath{\mathsf{MPa}}\xspace$
- 2. From the point just found, draw a line to the Y-axis to find the air consumption. The result is approximately 9*I* min (ANR).

A Caution

- 1. These flow rate characteristics are for fresh water (viscosity 1mPa·s, specific gravity 1.0).
- The discharge rate differs greatly depending on properties (viscosity, specific gravity) of the fluid being transferred and operating conditions (density, lifting range, transfer distance), etc.
- 3. If operated continuously at 10Hz, the diaphragm will reach its service life of 20 million cycles in approximately one month.

Selection from viscosity characteristic graph

Required specification example:

Find the pilot air pressure and pilot air consumption for a discharge rate of 200m / min, a total lifting range of 10m, and a viscosity of 15mPa s. Selection procedure

- 1. First find the ratio of the discharge rate for fresh water when viscosity is 15mPa s from the graph to the left. It is determined to be 48%.
- 2. Next, the viscosity of 15mPa s and the discharge rate of 200/min in the required specification example are converted to the discharge rate for fresh water. Since 48% of the fresh water discharge rate is equivalent to 200m/min in the required specifications, 200m/min ÷ 0.48 = approximately 420m/min, indicating that a discharge rate of 420m/min is required for fresh water.
- 3. Finally, find the pilot air pressure and pilot air consumption based on viewing of the flow rate characteristics.

Viscosity: Transfer is possible up to about 100mPa s.








Process Pump Built-in Solenoid Valve Type/Air Operated Type

Series PB1000

Operating Principle/Built-in Solenoid Valve Type/Air Operated Type



When air is supplied and the built-in solenoid valve is turned ON, air enters the drive chamber and the diaphragm moves to the left. Due to this movement, the fluid in the pump chamber passes through the upper check valve and is discharged to the OUT side.

When the solenoid valve is turned OFF, the air inside the drive chamber is evacuated to EXH, and the diaphragm is moved to the right by the return force of the return spring. Due to this movement, the fluid on the FLUID IN side passes through the lower check valve and is sucked into the pump chamber.

The PB1011 repeats this suction and discharge with the repetition of the built-in solenoid valve's ON/OFF operation. The PB1013 air operated type is operated by the ON/OFF operation of an external solenoid valve.






Series PB1000

Piping and Operation/Built-in Solenoid Valve Type/Air Operated Type





* The PB1013 air operated type has a plug in the air exhaust port EXH.

▲ Caution

Be sure that the discharge side OUT is on top when the pump is mounted. Supply clean air that has passed through an AF filter, etc., to the air supply port SUP. Air that contains debris or drainage, etc., will have an adverse effect on the built-in solenoid valve, and will cause malfunction of the pump. In cases that particularly require air cleaning, use a filter (Series


Operation

- 1. Connect air piping to the air supply port SUP, and connect piping for the transfer fluid to the suction port IN and the discharge port OUT.
- 2. Connect the solenoid valve lead wires to a 24VDC power supply. Red is (+) and Black is (–). (The PB1013 air operated type must be equipped with a separate solenoid valve.)
- 3. Using a regulator, set the pilot air pressure within the range of 0.2 to 0.7MPa. By continuously turning the 24VDC power ON/OFF the fluid flows from the suction port IN to the discharge port OUT. The pump performs suction with its own power even without priming.

AF) together with a mist separator (Series AM).

Maintain the proper tightening torque for fittings and mounting bolts, etc. Looseness can cause problems such as fluid and air leakage, while over tightening can cause damage to threads and parts, etc.

4. To stop the pump turn OFF the 24VDC power. Also be sure to turn OFF the power when the discharge side is closed. The manual override pin is used for manual operation when there is no electric power. Each time it is pressed, there is one reciprocal operation.










Process Pump Built-in Solenoid Valve Type/Air Operated Type

Series PB1000

Dimensions/Built-in Solenoid Valve Type/Air Operated Type







Related Products

VQZ2440

10.0 (0.55)

Related Products (Refer to the individual product catalogs for further details.)

Specifications

Valve construction

Type of actuation

Specifications

Valve construction

Type of actuation

Model

Rated flow rate

Imin (ANR)

Port size

(nominal size B)

Weight (kg)

Piping

Piping

Models

Model

Maximum operating pressure

Minimum operating pressure

Refer to Best Pneumatics (1) Page 1 12-1

Model

Maximum operating pressure

Minimum operating pressure


Maximum operating frequency

Refer to Best Pneumatics (1) Page 2.2-1


Effective area (Cv factor)

Effective area (Cv factor) Maximum operating frequency





3 port solenoid valve **SYJ34**



Mist Separator Series AM

Series AM separates and removes the oil mist in compressed air which is troublesome for ordinary filters, and removes fine particles of rust and carbon, etc., of $0.3\mu m$ or larger. Should be used as the air supply for driving pilot type and metal type solenoid valves.

Filter Regulator + Mist Separator Air Combination Series AC2040/3040

	Models			
r		Model	AC2040	AC3040
	Component	Filter regulator	AW2000	AW3000
	devices	Mist separator	AFM2000	AFM3000
	Dort oizo	Po	1/8	1/4
	Port size	Port size Rc		3/8
	Pressure g	auge port size Rc	1/8	1/8

AM150

300

1/8, 1/4, 3/8

0.38

Specifications

VQZ1440

8.1 (0.45)

Metal seal

3 position exhaust center

0.7MPa (high pressure type 1.0MPa)

0.1MPa

10Hz

Base mounted

Rubber seal

0.7MPa

0.15MPa

1.8 (0.1)

10HZ

VQZ1420

2.7 (0.15)

Body ported

SYJ314

N.C.

AM250

750

1/4, 3/8, 1/2

0.55

Compressed air 1.0MPa 0.05MPa
0.05MPa
1.5MPa
5 to 60°C
3µm (95% filtered particle diameter)
ax.1.0mg/m ³ (ANR) (approx. 0.8ppm) Note 2)
2 years, or when pressure drop reaches 0.1MPa

VQZ2420

3.6 (0.2)

Base mounted

SYJ324

N.O

Specifications

Model	AC2040	AC3040	AC4040	AC4040-06	
Proof pressure	1.5MPa				
Maximum operating pressure		1.0	ИРа		
Minimum operating pressure		0.05	MPa		
Regulating pressure range		0.05 to 0).85MPa		
Note 1) Rated flow rate /min (ANR)	150	330	800	800	
Ambient and fluid temperature	– 5 to	60°C (wi	th no free	ezing)	
Filtration degree	AW: 5µm, AFM: 0.3µm (95% filtered particle diameter)				
Downstream oil mist concentration	Max 1.0mgf/Nm ³ (approx. 0.8ppm)				
Case material		Polycar	bonate		
Construction/Filter regulator	Relief type				
Weight (kg)	0.63	0.97	1.91	1.99	

The rated flow rate varies depending on the set pressure. Note 2) When compressor discharge concentration is 30mg/Nm³

Compressed air

1.0MPa

0.05MPa

1.5MPa

5 to 60°C

99%

2 years, or when pressure drop reaches 0.1MPa

Drain Catch Series AMG

The AMG series is installed in air pressure lines to remove water droplets from compressed air. Use it when you want to remove water but air as dry as that from an air dryer is not necessary, or when a power supply for an air dryer is not available, etc.

Model	AMG150	AMG250
Rated flow rate Note) /min (ANR)	300	750
Port size (nominal size B)	1/8, 1/4, 3/8	1/4, 3/8, 1/2
Weight (kg)	0.38	0.55

Element life
Note) With auto drain is 0.15MPa

Specifications

Maximum operating pressure

Min. operating pressure

Ambient and fluid temperature

Dehumidification rate

Proof pressure

Fluid







Related Products

Related Products (Refer to the individual product catalogs for further details.)

Membrane Dyer Series IDG		Standard s	
		Mc	
Macromolecular membrane dryers	ting	Fluid	
that act like filters	of operating ditions	Inlet air p MPa	
	ige of o conditi	Inlet air ter	
	Range col	Ambient t	
	Standard perfor- mance	Outlet air pressure	

Model		Standard dew point -20°C					
	IVIODEI	IDG5	IDG10	IDG20	IDG30	IDG50	
ting	Fluid		Compressed air				
Range of operating conditions	Inlet air pressure MPa		0.3 to 0.85			0.3 to 1.0	
og (Inlet air temperature °C Note 1)		5 to 55			to 50	
Rar	Ambient temperature °C		-5 to 55		-5 1	to 50	
E + 8 Outlet air atmospheric		-20					
	Inlet air flow rate /min (ANR) Note 2)	62	125	250	375	625	
nance	Outlet air flow rate /min (ANR)	50	100	200	300	500	
ard perforn conditions	Purge air flow rate /min (ANR) Note 3)	12	25	50	75	125	
Standard performance conditions	Inlet air pressure MPa	0.7					
Sta	Inlet air temperature °C	25					
	Inlet air saturation temperature °C			25			
	Ambient temperature °C	25					
Dew point indicator purge air flow rate		 — 11/min (ANR) {inlet air pressure at 0.7MPa} 					
Port	size (nominal size B)	1/8, 1/4		1/4,	3/8		
	ht kg bracket)	0.25 (0.31)	0.43 (0.51)	0.66 (0.76)	0.74 (0.87)	0.77 (0.90)	

Note 1) With no freezing

Note 2) ANR indicates the flow rate converted to the value for 20°C at atmospheric pressure.

Note 3) Includes dew point indicator purge air flow rate of 1/min (ANR) (inlet air pressure at 0.7MPa). (except IDG1, IDG5)

Maintenance Part Lists

PAX1000

Diaphragm kit (PTFE)	KT-PAX1-31
Check valve kit	KT-PAX1-36
Switching valve parts kit	KT-PAX1-37
Pilot valve kit	KT-PA5-38
Pulsation attenuator control valve kit	KT-PAX1-39
PB1000	
Diaphragm kit	KT-PB1-2
Chask value kit	

Diapinaginia	INTER 2
Check valve kit	KT-PB1-1
Built-in solenoid valve kit	VJ314MY-5H

PA3000/Automatically operated type

i i teessii tatematean	, operated type
Diaphragm kit (PTFE)	KT-PA3-31
Diaphragm kit (NBR)	KT-PA3-32
Check valve kit	KT-PA3-36
Switching valve assembly kit	KT-PA3-37
Pilot valve kit	KT-PA5-38

PA3000/Air operated type

Diaphragm kit (PTFE)	KT-PA3-31
Check valve kit	KT-PA3-36

PA5000/Automatically operated type

· · · · · · · · · · · · · · · · · · ·	
KT-PA5-31	
KT-PA5-32	
KT-PA5-36	
KT-PA5-37	
KT-PA5-38	

PA5000/Air operated type

Diaphragm kit (PTFE)	KT-PA5-31
Check valve kit	KT-PA5-36

