# 3 Port Direct Operated Poppet Solenoid Valve Rubber Seal

# Series VT307

## Compact yet provides a large flow capacity

Dimensions (W x H x D)...30 x 54.5 x 33 (Grommet)

C: 0.71 dm<sup>3</sup>/(s·bar) {Rc 1/4 (Passage  $2 \rightarrow 3$ )}

#### Low power consumption

VT/VO307.....4.8 W DC/Standard type
VT/VO307Y
VT/VO307W).....2 W DC/Energy-saving type

## Suitable for use in vacuum applications


-101.2 kPa (For vacuum specifications type: VT/VO307V, VT/VO307W)


## A single valve with 6 valve functions

(Universal porting type)
Selective porting can provide 6 valve functions, such as N.C. valve, N.O. valve, Divider valve, Selector valve, etc.



#### JIS Symbol





#### Manifold

Marinola		
Model	Applicable manifold type	Accessory
VO307□	Common or individual exhaust	Function plate (DXT152-14-1A) Note) Mounting screw (NXT013-3)

Т

Conduit terminal

9

Note) It is not applied to "Continuous duty type". Refer to the accessories on page 4-7-5.

#### Option

Description	Part no.
Bracket	DXT152-25-1A (With thread)

## **⚠ Precautions**

I Be sure to read before handling. I For Safety Instructions and Solenoid Valve Precautions, refer to page 4-18-2.

### 

1. Make sure that dust and/or other foreign materials do not enter the valve from the unused port (e.g. exhaust port). Also, since there is a breathing port for the armature in the manual override part, do not allow accumulation of dust and/or other foreign materials to block bleed

#### How to Calculate the Flow Rate

For obtaining the flow rate, refer to page 4-1-6.

#### **Standard Specifications**

Type of actuation		Direct operated type 2 position single solenoid			
Fluid		Air			
Operating pressure range		0 to 0.9 MPa			
Ambient and fluid temperature	е	-10 to 50°C (No freezing. Refer to page 4-18-4.)			
Response time (1)			20 ms or less (at the pressure of 0.5 MPa)		
Max. operating frequency			10 Hz		
Lubrication		Not required (Use turbine oil Class 1 ISO VG32, if lubricated.)			
Manual override		Non-locking push type			
Mounting orientation			Unrestricted		
Shock/Vibration resistance (2)			150/50 m/s <sup>2</sup>		
Enclosure		Dustproof			
Electrical entry			Grommet, Grommet terminal, Conduit terminal, DIN terminal		
Coil roted voltage (V)	AC (50	)/60 Hz)	100, 200, 24*, 48*, 110*, 220*, 240*		
Coil rated voltage (V)		C	24, 6*, 12*, 48*, 100*		
Allancable colleges floretoeties			45 +- 1400/		

Allowable voltage fluctuation -15 to +10% of rated voltage Inrush 12.7 VA (50 Hz) 10.7 VA (60 Hz) Apparent power (3) (4) AC Holding 7.6 VA (50 Hz) 5.4 VA (60 Hz) Power consumption (3) (4) DC Without indicator light: 4.8 W, With indicator light: 5 W Light/Surge voltage suppressor AC ZNR (Varistor), Neon bulb (Not applicable for grommet type) DC Diode, LED (Neon bulb for 100 V or more)

\* Option

Note 1) Based on dynamic performance test, JIS B 8374-1981. (Coil temperature: 20°C, at rated voltage, without surge suppressor)

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 1000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) At rated voltage

Note 4) The value is different for continuous duty type (VT307E), and energy-saving type (VT307Y/W). Refer to "Option" shown below.

#### Flow Characteristics/Weight

	Dort	Flow characteristics								Mojaht				
Valva model	Port size	1 → 2	(P →	A)	$2 \rightarrow 3$	(A →	R)	3 → 2	(R →	A)	2 → 1	(A → I	P)	Weight
	3120	C [dm3/(sbar)]	b	Cv	C [dm3/(sbar)]	b	Cv	C [dm³/(sbar)]	b	Cv	C [dm3/(sbar)]	b	Cv	Grommet
VT307		0.71	0.35	0.18	0.68	0.27	0.17	0.65	0.36	0.17	0.63	0.35	0.17	
VT307V (Vacuum spec. type)	1/8	0.71	0.33	0.18	0.00	0.27	0.17	0.65	0.30	0.17	0.63	0.35	0.17	
VT307E (Continuous duty type)														
VT307Y (Energy-saving type)		0.41	0.26	0.10	0.44	0.35	0.11	0.48	0.27	0.12	0.35	0.33	0.10	
VT307W (Energy-saving, Vacuum spec. type)														0.14 kg
VT307		0.71	0.31	0.19	0.71	0.25	0.17	0.68	0.33	0 17	0.71	0.26	0.18	0.14 kg
VT307V (Vacuum spec. type)		0.71	0.51	0.19	0.71	0.25	0.17	0.00	0.33	0.17	0.71	0.20	0.16	
VT307E (Continuous duty type)	1/4													
VT307Y (Energy-saving type)		0.49	0.20	0.12	0.44	0.34	0.11	0.48	0.17	0.12	0.46	0.28	0.11	
VT307W (Energy-saving, Vacuum spec. type)														

Note) Values for a single valve unit. It differs in the manifold case. Refer to manifold specifications on page 4-7-5.

#### Option

#### Continuous duty type: VT307E

Exclusive use of VT317E recommended for continuous duty with long time loading.

#### 

- 1. This model is for continuous duty, not for high cycle rates. But even in low cycle rates, if energizing the valve more than once a day, please consult with
- 2. Energizing solenoid should be done at least once in 30 days.

#### Specifications different from standard are as follows.

	Inrush	7.9VA (50 Hz) , 6.2VA (60 Hz)		
	Holding	5.8VA (50 Hz) , 3.5VA (60 Hz)		
Power consumption/DC	2 W, 2.2 W (With indicator light)			
Response time (1)	30 ms or less (at the pressure of 0.5 MPa			

Note1) Refer to "Response time" of standard specifications

Note 2) For the flow characteristics, refer to "Flow Characteristics".

#### Energy-saving type: VT307Y (VT307W)

If low power consumption is required for electronic control, "VY307Y(W)" (2 W DC) is recommended.

Specifications different from standard are as follows.

Power consumption/DC |2 W, 2.2 W (With indicator light) \* Response time (1) 25 ms or less (at 0.5 MPa)

\* 100 VDC: 2.4 W

Note 1) Refer to "Response time" of standard specifications.

to "Flow Characteristics".

Note 2) For the flow characteristics, refer

#### Vacuum spec. type: VT307V (VT307W)

This vacuum model has less air leakage than the standard model under low pressure. It is recommended for vacuum application.

#### △ Caution

1. Since this valve has slight air leakage, it can not be used for vacuum holding (including positive pressure holding) in the pressure container.


Specifications different from standard are as follows.

Operating pressure range | -101.2 kPa to 0.1 MPa



#### 3 Port Direct Operated Poppet Solenoid Valve Rubber Seal Series VT307

#### Construction



## Operation principle <De-energized>

Spool valve ② is pushed upward by the return spring ③, port  $\square$  is closed, and then port  $\square$  and port  $\square$  are opened.

Air flow direction:

 $\mathsf{Port} \ \boxed{\mathsf{P}} \longleftrightarrow \mathsf{Block}, \ \boxed{\mathsf{A}} \longleftrightarrow \boxed{\mathsf{R}}$ 

#### **Component Parts**

Energized
(A)2 (I)

When an electric current is applied to the molded coil ④, the armature ⑤ is attracted to the core ⑥, and through the push rod ⑦, it pushes down the spool valve ②. Then, port P and port A are connected. At this time, there will be gaps between the armature ⑤ and the core ⑥, but the armature will be magnetically attracted to the core ⑥.

Air flow direction:

<Energized>

 $\mathsf{Port}\: \overline{\mathbb{P}} \longleftrightarrow \mathsf{Port}\: \overline{\mathbb{A}}\:,\: \mathsf{Port}\: \overline{\mathbb{R}} \longleftrightarrow \mathsf{Block}$ 

No.	Description	Material	Note
1	Body	Aluminum die-casted	Color: Platinum silver
2	Spool valve	Aluminum, NBR	
3	Return spring	Stainless steel	
(4)	Molded coil	Resin	

#### **How to Use DIN Terminal**

#### 1. Disassembly

- After loosening the thread (1), then if the housing (2) is pulled in the direction of the thread, the connector will be removed from the body of equipment (solenoid, etc.).
- 2) Pull the screw (1) out of the housing (2).
- 3) On the bottom part of the terminal block (3), there's a cut-off part (9). If a small flat head screwdriver is inserted between the opening in the bottom, terminal block (3) will be removed from the housing (2). (Refer to "Figure 1".)
- 4) Remove the cable gland (4) and plain washer (5) and rubber seal (6).

#### 3. Wiring

- Passing through the cable (7), cable gland (4), plain washer (5), rubber seal
   (6) in this order, and then insert into the housing (2).
- From the terminal block (3), loosen the screw (11), then pass the lead wire (10) through, then again tighten the screw (11).
  - Note 1) Tighten within the tightening torque of 0.5 N·m ±15%.
  - Note 2) Cable (7) external: ø6 to ø8 mm Note 3) Crimped terminal like roundshape or Y shape cannot be used.

#### **Connector for DIN Terminal**


Description	Part no.
DIN connector	B1B09-2A

#### 3. Assembly

1) Passing cable gland (4), washer (5), rubber seal (6), housing (2) in this order through cable (7) and connect to terminal block (3) and then set the terminal block (3) to the housing (2).

(Push it down until you hear the click sound.)


- Putting rubber seal (6), plain washer (5), in this order into the cable introducing slit on the housing (2), then further tighten the cable gland (4) securely.
- 3) Insert the gasket (8) between the bottom part of terminal block (3) and a plug attached to equipment, and then screw (1) in from the top of the housing (2) to tighten it
  - Note 1) Tighten within the tightening torque of 0.5 N·m  $\pm 15\%$ .
- Note 2) Connector orientation can be changed by 180 degrees depending on how to assemble the housing (2) and the terminal block (3).




### **△** Caution

#### **Light/Surge Voltage Suppressor**

AC, 100 VDC or more




48 VDC



#### **Electrical Connection**

DIN terminal and terminal (with light/surge voltage suppressor) are connected inside as in the figure below. Connect to the corresponding power supply.



- Applicable cable O.D.
   Type T: ø4.5 to ø7 mm
   Type E: ø2.3 to ø2.8 mm
   Type D: ø6 to ø8 mm
- Applicable crimp terminal
   Type E/T: 1.25-3, 1.25-3S
   1.25Y-3N, 1.25Y-3S

(Round or "Y" shaped crimped terminals ) can be not used for type "D".

Lead Wire Color						
Color						
Blue						
Red						
Red (+), Black (-)						
Gray						

V100 SY

SYJ

VK

٧Z

VT

۷P

VG VP

S070

VQ VKF


VQZ

VZ

٧S

VFN

#### Dimensions (Interchangeable with "VT301" for mounting)



V100

SY

SYJ

٧K

٧Z

**VP** 

۷G

**VP** 

**S070** 

VQ

VKF

VQZ

٧Z

VS

**VFN** 

## Series VT307

## **Manifold Specifications**


VT307 manifold is B mount style and available both as a common exhaust and individual exhaust model.

Manifold valve can be easily converted from N.C. (Normally Closed) to N.O. (Normally Open) merely by turning over the switch cover.



VV307-01-063-□-F

#### **How to Order Manifold**



**Manifold Specifications** 

Manifold type			B mount				
Max. number of stations			20 stations Note)				
Applicable solenoid valve			VO307□-□□□				
Exhaust port			Port	location (Dir	ection)/Por	t size	
Symbol	Type	Р		A	١	R	
2	Common	Base (Side)		Base	(Side)	Base (Side)	
-	Common	1/8	3	1/	8	1/8	
3	Individual Base (		Side)	Base	(Side)	Base (Top)	
3	IIIuiviuuai	1/2	1	1/8,	1/4	1/8	

exhaust from both of the R port.

Option

Description	Part no.
Blanking plate (With gasket, screw) Note)	DXT060-51-13 A

**Accessory for Applicable Solenoid** 

Description	Part no.	Qty.
Function plate (With gasket) Note)	DXT152-14-1 A	1 pc.
Mounting screw	NXT013-3	2 pcs.

Note) DXT060-51-13B, DXT152-14-1B are for energizing continuously.

#### Flow Characteristics/Weight

	Flow characteristics									\\/a:ab4			
Valve model	1 → 2 (P → A)		$2 \rightarrow 3 (A \rightarrow R)$			$3 \rightarrow 2 (R \rightarrow A)$			2 → 1 (A → P)			Weight	
	C [dm³/(s·bar)]	b	Cv	C [dm3/(s·bar)]	b	Cv	C [dm3/(s-bar)]	b	Cv	C [dm3/(s-bar)]	b	Cv	Grommet
VO307	0.34	0.28	0.089	0.34	0.22	0.082	0.36	0.28	0.091	0.34	0.18	0.080	0.14 kg
VO307V (Vacuum spec. type)													
VO307E (Continuous duty type)	0.30 0.	0.18	0.070	0.30	0.15	0.072	0.32	0.20	0.075	0.30	0.15	0.069	
VO307Y (Energy-saving type)													
VO307W (Energy-saving, Vacuum spec. type)													


### **⚠** Precautions

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 4-18-2.

#### Mounting

## **⚠** Warning

When mounting a valve on the manifold base, N.C. and N.O. can be reversed by a function plate orientation. Also, since cylinder also acts reversely, confirm if the function plate is correctly mounted or not.



#### Changing from N.C. to N.O.

## **⚠** Caution

This product is delivered as N.C. valve. If N.O. valve is needed, remove mounting screws of the required valve and turn over the function plate. (Make sure that there are gaskets on both sides of the plate.) Then, tighten the mounting screws to fix the valve to the manifold base.




Figure: For N.C.

Specifications	Function plate						
N. C.	No mark						
N. O.	NO						

## **△** Caution

- Each valve is fixed to the manifold base with two M4 mounting screws. Tighten the screws evenly when re-mounting.
- 2. For mounting, tighten M4 or equivalent screws evenly into the mounting holes of the manifold base.

Tightening torque of the mounting screw (M4): 1.4 N·m


#### **Port Direction**

### **⚠** Caution

**1.** For the common exhaust type, pressurization or evacuation of the R port can cause a malfunction.

### 3 Port Direct Operated Poppet Solenoid Valve Rubber Seal Series VT307

**Dimensions: Common Exhaust (Interchangeable with VT301 for mounting)** 



**SMC** 

V100

SY

SYJ

VK VZ

\/<del>--</del>

VI

VP

VG

VP

S070 VQ

VKF

VQZ

٧Z

٧S

VFN

#### Dimensions: Individual Exhaust (Interchangeable with VT301 for mounting)

