1


Paddle Style Flow Switch Series IF3

IF3 series flow switches detect and confirm liquid flow, generally used in fields such as air conditioning, water supply equipment, etc.

- Piping sizes ranges from 3/4B to 6B.
- Wide range of applicable fluids.
 Wetted metal part materials: Copper alloy,
 Stainless steel
- Various enclosures (No water protected).
 Open type, Dripproof/Rainproof, Splashproof

/Low jetproof type





Specifications

	Copper alloy	Water/Non corrosive liquid					
Fluid	Stainless steel 304	Liquid, which do not corrode stainless steel 304.					
Max. pressure		1 MPa					
Water resistance		1.75 MPa					
Insulation resistance		100 M Ω (500 DC by megameter)					
Withstand voltage		1500 VAC for one min.					
Contact		1ab					
Port size	3/4, 1						

Micro Switch Ratings

	N	on inducti	ive load (/	۹)	Inductive load (A)				
Voltage	Load resistance		Light	load	Inducti	ve load	Motor load		
	N.C.	N.O.	N.C. N.O.		N.C. N.O.		N.C.	N.O.	
125 VAC	15	15	4 2		10 10		4	2	
250 VAC	15	15	3	1.5	10 10		3	1.5	
8 VDC	15	15	3	1.5	15	15	5	2.5	
14 VDC	15	15	3 1.5		10	10	5	2.5	
30 VDC	6	6	3	1.5	5	5	5	2.5	
125 VDC	0.5	0.5	0.3 0.3		0.05	0.05	0.05	0.05	
250 VDC	0.25	0.25	0.2	0.2	0.03	0.03	0.03	0.03	



ZSE□ ISE□

PSE

^zSE3

PS

^ZSE¹

ZSP

ISA2

IS□

ZSM

PF2□

IF 🗆

Data


Fluid and Ambient Temperature Range

Fluid temperature	Applicable ambient temperature Note)
70°C or less	70°C (70°C) or less
80°C	58°C (60°C) or less
90°C	47°C (50°C) or less
100°C	35°C (40°C) or less

Note) () For IF32

 \ast To protect the microswitch, ambient temperature must be lowered when the fluid temperature exceeds 70°C.

Construction



Component Parts

No.	Description	Material								
INO.	Description	IF30□	IF32□							
1	Cover	SPCD	SPCD	12 ADC						
2	Mounting plate	SPCC	Stainless steel 30							
3	Bellows	PBP or Stainless steel 304								
(4)	Body	C3604B or Stainless steel 304								
5	Mobile bar	C2700W or Stainless steel XM7								
6	Paddle	Stainless steel 304								
7	O-ring	NBR or FPM								

Enclosure

Open type	Using indoors away from water drop.					
Dripproof/Rainproof type (JIS C 0920)	When using indoors or outdoors, where it is exposed to water drop. (Equivalent to IP42)					
Splashproof/ Low jetproof type (JIS C 0920)	Sealed construction. When using in a bad environment, such as outdoors, or areas exposed to water stream temporarily, or near the coast. (Equivalent to IP44)					

Flow Characteristics

Fluid: Water, Outlet pressure: 0 MPa Sealing thread depth: 9 mm (3/4), 11 mm (1)

	Mounting							
Flow	IVIOU	nung	Mini	mum	Maxi	mum	ON-flow rate/setting	
switch	Port size	Paddle ON flow		OFF flow (min)	ON flow	OFF flow (min)	(m/s)	
	3/4	Long	14	7	38	33	0.66 to 1.79	
IF3□0-06	3/4	Middle	18	9	50	44	0.85 to 2.36	
3/4 Short 22	11	60	60 53 1.0					
	1	Short	20	10	60	55	0.56 to 1.67	
	1 1/4	Short	34	17	100	90	0.57 to 1.67	
	1 1/2	Short	52	26	160	140	0.63 to 1.95	
IF3□1-10	2	Middle	45	23	140	125	0.34 to 1.06	
	2 1/2	Middle	90	45	280	250	0.41 to 1.29	
	3	Middle	80	40	250	220	0.26 to 0.81	
	4	Long	170	85	550	480	0.33 to 1.05	
	5	Long	300	150	1,000	870	0.37 to 1.24	
	6	Long	460	230	1,500	1,300	0.40 to 1.32	
	1	Short	36	18	110	100	1.00 to 3.05	
	1 1/4	Short	54	27	160	140	0.90 to 2.67	
	1 1/2	Short	90	45	270	230	1.10 to 3.29	
	2	Middle	90	45	270	230	0.68 to 2.05	
IF3□3-10	2 1/2	Middle	160	80	500	420	0.74 to 2.30	
	3	Long	160	80	500	420	0.52 to 1.63	
	4	Long	320	160	1,000	800	0.61 to 1.91	
	5	Long	560	280	1,800	1,450	0.69 to 2.23	
	6	Long	800	400	2,600	2,000	0.70 to 2.28	

ON-flow: Flow volume under which a microswitch starts activation while flow is increasing.

OFF-flow: Flow volume under which a microswitch starts activation while flow is decreasing.


• The maximum flow is twice the maximum ON-flow.

• Operating flow volume varies depending on sealing depth and direction, etc. Data shows the reference value.


SMC

Series IF3

ON-flow Change due to Pressure



Pressure Drop Curve



A Precautions

Be sure to read before handling. Refer to pages 16-14-3 to 16-14-4 for Safety Instructions and Common Precautions on the products mentioned in this catalog, and refer to pages 16-1-11 to 16-1-13 for Precautions on every series.

Mounting & Wiring

🗥 Caution

- 1. Mount the switch on top of horizontal pipe so that fluid flow is in the direction of the arrow.
- Sealing depth should be 9 mm \pm 1 mm for 3/4B and 11 mm \pm 1.2 mm for 1B.
- **2.** Mounting orientation is only allowed to install it perpendicularly to the horizontal pipe.
- **3.** Provide a straight pipe portion that corresponds to approximately 5 times the bore of the pipe before and after the area of the pipe on which the product is installed, thus keeping the product as far away as possible from the elements that disturb the flow, such as elbows or valves.
- **4.** Three types of paddles, short, medium, and long, are provided with each model. Use one of them according to the pipe size and the set flow rate.
- 5. When installing a paddle on IF3*O type, piping may be interfered with by the tip of a paddle. Because this is used to detect a small flow rate, and to narrow the distance between a paddle and piping, additional
- the distance between a paddle and piping, additional machining of the paddle tip may be necessary to eliminate interference between the two.
- Use pipe fittings that comply with JIS specifications. For 3/4B to 3B, use commercially available union tees of different diameters. For 4B to 6B, use a 1B socket that has been cut in half and

welded.


- 7. When using piping which is non-standard, piping may interfere with the paddle. When this happens, please machine the paddle accordingly.
- 8. It cannot be used when a water hammer or pulsation pressure is applied to the fluid.

Applicable fittings

For pipe fitting 3/4B through 3B F

: JIS B 2302 : JIS B 3452

Piping B	Reducing tees B
1	1 x 1 x 1
1 ¹ / ₄	1 ¹ / ₄ x 1 ¹ / ₄ x 1
1 ¹ / ₂	1 ¹ / ₂ x 1 ¹ / ₂ x 1
2	2 x 2 x 1
2 ¹ / ₂	2 ¹ / ₂ x 2 ¹ / ₂ x 1
3	3 x 3 x 1
Reducing	tees B: JIS B 2301



- 9. Wire the microswitch according to the symbols on the upper insulators. (They will be opposite the terminal symbols on the microswitch. The terminals are screw terminals.)
 9. Threads used for the terminals are M4 type.
- **10.** Threads used for the terminals are M4 type.

Internal wiring diagram

	A (N.O.)	Symbol	Contact
C (COM)	<u>~ A (N.O.)</u>	С	Common
	— B (N.C.)	Α	Normally Open
	<u> </u>	В	Normally Closed

Adjusting

ACaution

- 1. Flow adjustment is done by turning the flow adjusting screw with Phillips screwdriver. Turning clockwise can increase the set flow and turning counterclock can decrease the set flow.
- 2. Flow rate % relation to the number of turns is shown in the table below. However, this is just a guide. For precise setting use a flow meter.

Flow adjusting screw (Rotations)	0	1	2	3	4	5	6	7	8	9	10	11	12
Contact ON-flow (%)	30	40	50	59	68	74	80	85	89	93	96	98	100

3. The flow rate setting point is set at the ON-flow rate. Therefore, in case of 1a contact, ON signal is output when the fluid with higher flow than the setting flow rate is flown. In the case of the 1b contact, the OFF signal is output when the flow rate has decreased. Refer to the flow rate characteristics table for details on the

operation flow rate. 4. Do not touch the two types of stop screws that are indicated in

- the construction diagram.5. To prevent the chattering that is associated with the fluctuation of the operating flow rate, set the difference between the set
- of the operating flow rate, set the difference between the set flow rate and the operating flow rate so that it is as large as possible.
- **6.** Use at or below the maximum operating pressure and maximum flow rate.
- 7. Spare parts

Short, medium, and long paddles are provided as a 3 piece set with each model, so arrange them as indicated below. There is no compatibility between the paddle for a 3/4B connecting bore and for a 1B because their installation pitches differ.

Arrangement example: Paddle set for IF300-06-00 (Part number are not existed.)

3


Socket


Pipe





Dimensions

Standard type: 300/301/303










IF□ Data

Series **IF3**

Flow Rate vs. Flow Speed



(): Gas pipe bore sizes